



DHE, DEL, DHB-E




Pull out and down to view rating plate.

DHF




Located on the base on the unit.

Simplex




Pre 2020 DHE, DEL, DHB-E




Pull out and down to view rating plate.


DHCE




DEM 6




SNE, SNU




SHC




WWK



HTE 4, HTE 5, Ultronic



CNS Range



CON | CK

